


EXPLODED VIEW



PART LIST

Item#	DESCRIPTION	Item#	DESCRIPTION
1	Seat	41	seat post
2	alloy clip R& L	42	chain guard screw (M5)
3	Release lever spring	43	flywheel
4	Release lever w/washer	44	flywheel adjuster bolt
5,7	crank arm (set)	45	inner chain guard screw (M6)
6	outer chain guard	45-1	inner chain guard washer
8	foot tube nut	46	bolt for sensor support
9	foot tube washer	47	cable clip
10	foot tube bolt	48	bolt for cable clip
11	pedal	49	release lever fixed bolt
12	rear foot tube (set)	50	release lever plastic washer
13	foot adjuster pad	51	release lever washer
14	foot tube end cap	52~55	magnetic holder w/magnetic, bolt, fixed pin
15	moving wheel	56,57	E clip w/ fixed pin
15-1	axle bolt for moving wheel	58	spring
16	front foot tube (set)	59	connection bracket
17,18	brake pad w/holder	60	plate for screw
19	screw & nut for brake pad	61	handlebar release lever w/washer & O clip
20	washer for brake pad	62	fender
21	handlebar w/slider	63	bolt & washer for fender
22	crank bolt	64	sprocket bracket for resistance knob
23	BB bearing	65	bolt for sprocket bracket
24	BB axle w/plate	66	idler
25	flywheel nut cap	67	belt wheel w/screw
26	flywheel security washer	68	foot tube support nut
27	flywheel axle w/bearing	69	outer chain guard bolt (M5 3/16")
28	computer	70	bolt
29	bottle cage	90	sensor & cable
30	screw for bottle cage		
31	brake system		
32	chain guard screw (M6)		
33+39	front chain cover (R/L)		
34	bottle		
35	screw & washer for plate		
36	belt		
37	handlebar post		
38	rubber sleeves		
40	seat slider		