


EXPLODED VIEW

(Use key numbers to reference the part numbers.)





PARTS LIST

Part No.	Description	Spec.
1	MAIN FRAME	
2	BASE FRAME	
3	LEFT UPRIGHT	
4	RIGHT UPRIGHT	
5	COMPUTER FRAME	
6	PLATING TUBE	
7	MOVING TUBE	
8	INCLINE FRAME	
9	LEFT HANDLEBAR	
10	RIGHT HANDLEBAR	
11	MOTOR FRAME	
12	FRONT CONNECT PLATE	
13	CONNECT PLATE	
14	METAL PLATE FOR A-WING SOCKET	
15	U SHAPE PLATE	
16	FOOT PLATE	
17	FOOT RAIL WASHER	
18	DEVICE PLATE	
19	FRONT ROLLER	
20	REAR ROLLER	
21	GAS SHOCK	
22	BOLT	
23	ALLEN KEY	5mm
24	MOVING WHEEL END CAP	
25	SPRING	
26	SAFETY KEY PLATE	
27	BOLT	M10*20 11
28	SLEEVE	
29	CONNECT TUBE	



PARTS LIST (con't)

Part No.	Description	Spec.
30	LEFT REAR END CAP	
31	RIGHT REAR END CAP	
32	PLASTIC STOP COLLAR	
33	INNER TUBE CAP	
34	ADJUST WHEEL	
35	MOTOR BOTTOM COVER	
36	RING CORD	
37	POWER CABLE CORD	
38	RUNNING BELT	
39	BLUE CUSHION	
40	BLACK CUSHION	
41	LEFT HANDLEBAR COVER	
42	RIGHT HANDLEBAR COVER	
43	MONITOR LEFT BACK COVER	
44	MONITOR RIGHT BACK COVER	
45	SIDE RAIL	
46	A-WING	
47	MONITOR TOP COVER	
48	MONITOR DISPLAY COVER	
49	INNER TUBE CAP	
50	MOVING WHEEL END CAP	
51	GRIP FOAM	
52	END CAP	
53	FLAT WASHER	
54	MOVING WHEEL	
55	SAFETY KEY BALL	
56	FLAT WASHER	
57	DRIVING BELT	
58	MOTOR COVER	
59	SCREW	M5



PARTS LIST (con't)

Part No.	Description	Spec.
60	SCREW	M6
61	SCREW	M8
62	SCREW	M10
63	BOLT	M3
64	SCREW	M8*20
65	SCREW	M8*46 20
66	BOLT	M6*50
67	BOLT	M6*75
68	BOLT	M6*32
69	BOLT	M6*20
70	BOLT	M8*25 15
71	BOLT	M8*35 20
72	BOLT	M8*40 20
73	BOLT	M8*50 20
74	BOLT	M10*25
75	BOLT	M8*52 20
76	BOLT	M8*60
77	BOLT	M8*65 20
78	BOLT	M10*45 20
79	BOLT	M10*110 20
80	SCREW	M3*10
81	SCREW	M3*6
82	SCREW	M4*6
83	SCREW	M5*8
84	SCREW	M5*8
85	SCREW	M5*12
86	SCREW	M5*16
87	SCREW	M5*35
88	SCREW	M5*40 10
89	SCREW	M6*16
90	SCREW	ST4.2*35
91	SCREW	ST4.2*12
92	SCREW	ST2.9*8
93	SCREW	ST4.0*15
94	FLAT WASHER	8
95	SPRING WASHER	8
96	FLAT WASHER	5

P370



PARTS LIST (con't)

Part No.	Description	Spec.
97	FLAT WASHER	6
98	LOCK WASHER	10
99	FLAT WASHER	10
100	SCREW	M6*10
101	WASHER	φ8*φ22*2.0
102	TOP CONTROLLER	
103	BOTTOM CONTROLLER	
104	TRANSFORMER	
105	HANDLE PULSE	
106	HAND PUSLE UPPER WIRE	
107	HAND PUSLE MIDDLE WIRE	
108	MONITOR UPPER WIRE	
109	MONITOR MIDDLE WIRE 1	
110	MONITOR MIDDLE WIRE 2	
111	MONITOR LOWER WIRE	
112	MAGNETIC RING	
113	MAGNETIC CORE	
114	AC SINGLE WIRE	120
115	AC SINGLE WIRE	150
116	AC SINGLE WIRE	150
117	SINGLE WIRE 1	350
118	SINGLE WIRE 2	350
119	EARTH WIRE	
120	SAFETY KEY COMPONENT	
121	SPEED SENSOR	
122	SWITCH BOARD	
123	SILICON	
124	POWER SWICH	
125	BREAKER	
126	POWER CABLE	
127	RUNNING BOARD	
128	DC MOTOR	
129	INCLINE MOTOR	



PARTS LIST (con't)

Part No.	Description	Spec.
130	LOUDSPEAKER FIXING PLASTIC	
131	LOUDSPEAKER SUPPORTING PLASTIC	
132	Mp3	
133	LOUDSPEAKER	
134	LEFT LOUDSPEAKER COVER	
135	RIGHT LOUDSPEAKER COVER	
136	ANTI-SLIPPERY RUBBER	
137	WRENCH/SCREW DRIVER	S=13, 14, 15
138	MONITOR OVERLAY	
139	BOX WRENCH	S=5, 13, 14
140	FLAT WASHER	
141	SENSOR CONNECT BOARD	